

## Short Test

### Engine Module Siemens EMS SDI 6.1

Current Fault Codes



**P0500:**

Ignition Coil "B" Secondary Circuit  
Upper limit value exceeded



**C1200:**

Ignition Coil B Primary/secondary Circuit  
No signal/communication



**B0300:**

Transmission Mount Valve -1/-2- -N262/-N263- Short circuit to B+  
Value below lower limit value



**P0200:**

Cyl.2 Misfire Detected  
Upper limit value exceeded

### Dual Clutch / Doppelkupplung - PDK

Current Fault Codes



:



:



:



:

### Steering Wheel Electronics



No Faults Found

### CAN Gateway

Current Fault Codes



**1025 / 401:**

Current distributor, terminal 30 reset  
Warning Indicator Off  
Test Completed This Monitoring Cycle  
Test Not Failed Since Last Clear  
Test Completed Since Last Clear  
Not Pending DTC  
Test Not Failed This Operation Cycle  
Fault Active



**12656791 / c12097:**

Check A/C unit fault memory content  
Warning Indicator Off

Test Completed This Monitoring Cycle  
Test Not Failed Since Last Clear  
Test Completed Since Last Clear  
Not Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**Instrument cluster for 970, 958**

No Faults Found

**Door module front right**

No Faults Found

**Door module front left****Door module rear right****Door module rear left****Body Control Module Rear****Body Control Module Front****Tire Pressure Monitor**

No Faults Found

**Radio PCM 3.1 CDR31**

No Faults Found

**Backup Camera**

No Faults Found

**Park Assist**

No Faults Found

**Heating and Air Conditioning - HVAC**

Current Fault Codes



**3277300 / 3201f4:**

Warning Indicator Off  
Test Completed This Monitoring Cycle  
Test Not Failed Since Last Clear  
Test Completed Since Last Clear  
Not Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**Electronic Parking Brake**

Current Fault Codes



**3277300 / 3201f4:**

Warning Indicator Off  
Test Completed This Monitoring Cycle  
Test Not Failed Since Last Clear  
Test Completed Since Last Clear  
Not Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**Porsche Stability Management / Anti-lock Brake System (ABS)**

Current Fault Codes



**12656768 / c12080:**

Check engine control unit fault memory content  
Warning Indicator On  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive



**12656801 / c120a1:**

Check center-diff. lock control unit fault memory content  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive



**8325 / 2085:**

Sport mode, center-diff. lock, faulty  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**8330 / 208a:**

Sport mode, faulty  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**Porsche Stability Management / Anti-lock Brake System (ABS)**

Current Fault Codes

**12656768 / c12080:**

Check engine control unit fault memory content  
Warning Indicator On  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**12656801 / c120a1:**

Check center-diff. lock control unit fault memory content  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**8325 / 2085:**

Sport mode, center-diff. lock, faulty  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**8330 / 208a:**

Sport mode, faulty  
Warning Indicator Off  
Test Not Completed This Monitoring Cycle  
Test Failed Since Last Clear  
Test Not Completed Since Last Clear  
Pending DTC  
Test Not Failed This Operation Cycle  
Fault Passive

**Airbag**

No Faults Found

### Rear lid - Tailgate

No Faults Found



### Lane Change Assistant

#### Headlight Right

No Faults Found



#### Headlight Left

No Faults Found



### Seat Electronics Passenger

Current Fault Codes



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**



Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



**2:**

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal



2:

Implausible signal

**Seat Electronics Driver**